

# METAL SHADE ASSEMBLY INSTRUCTIONS

# Ongo

CAP

THIN WASHER

SHADE

SCREW


THICK WASHER

BASE




Step 1

Unscrew the cap and remove the thin plastic washer



Step 2

Align the center of the shade over the screw and gently place the shade on top of the base



Step 3

Fix the cap with the thin washer on top of the shade

# Ongo

CHARGING INSTRUCTIONS

CON TARDI®

Itzelan  
Lana


Please Note:

To verify that the lamp is correctly recharging, TURN ON the lamp while it is connected to the electrical system.

·If the lamp is completely out of power it must light up.


·If the lamp is not completely out of power the light intensity must increase.

IF NOT you must check if the jack is properly inserted into the base socket.



Step 4

Turn off the lamp and insert the jack into the lamp base socket



Step 5

The cable must pass through the base slot to grand the lamp stability during the battery charging



Step 6

Put the lamp on a plane surface and connect the pug to charge the lamp. Charge for 4 hours with lamp turned off or 16 hours with lamp turned on